

# Terminal Strap for Junction Box

A terminal strap is flat and mounts on top of the brackets for Junction Box. The straps can be positioned anywhere along the brackets and are held in place with spring locking nuts.



## FEATURES

---

Does not work with DIN rail-mounted terminal blocks

Terminal blocks are not included

## SPECIFICATIONS

Table 1/1

| Catalog Number | Article Number | Material   | Finish                       | Color | Thickness | Useable Space |
|----------------|----------------|------------|------------------------------|-------|-----------|---------------|
| A12JS          | 54720          | Mild Steel | Galvanized,<br>Powder Coated | White | 2.66mm    | 219mm         |
| A16JS          | 54740          | Mild Steel | Galvanized,<br>Powder Coated | White | 2.66mm    | 321mm         |
| A10JS          | 54710          | Mild Steel | Galvanized,<br>Powder Coated | White | 2.66mm    | 168mm         |
| A14JS          | 54730          | Mild Steel | Galvanized,<br>Powder Coated | White | 2.66mm    | 270mm         |
| A8JS           | 54700          | Mild Steel | Galvanized,<br>Powder Coated | White | 2.66mm    | 117mm         |

## WARNING

nVent products shall be installed and used only as indicated in nVent's product instruction sheets and training materials. Instruction sheets are available at [www.nvent.com](http://www.nvent.com) and from your nVent customer service representative. Improper installation, misuse, misapplication or other failure to completely follow nVent's instructions and warnings may cause product malfunction, property damage, serious bodily injury and death and/or void your warranty.



Our powerful portfolio of brands:

**CADDY ERICO HOFFMAN ILSCO SCHROFF TRACHTE**