

Terminal Strap for Junction Box

A terminal strap is flat and mounts on top of the brackets for Junction Box. The straps can be positioned anywhere along the brackets and are held in place with spring locking nuts.



FEATURES

Does not work with DIN rail-mounted terminal blocks

Terminal blocks are not included

SPECIFICATIONS

Table 1/1

Catalog Number	Article Number	Material	Finish	Color	Thickness	Useable Space
A12JS	54720	Mild Steel	Galvanized, Powder Coated	White	12ga	8.62in
A16JS	54740	Mild Steel	Galvanized, Powder Coated	White	12ga	12.62in
A10JS	54710	Mild Steel	Galvanized, Powder Coated	White	12ga	6.62in
A14JS	54730	Mild Steel	Galvanized, Powder Coated	White	12ga	10.62in
A8JS	54700	Mild Steel	Galvanized, Powder Coated	White	12ga	4.62in

WARNING

nVent products shall be installed and used only as indicated in nVent's product instruction sheets and training materials. Instruction sheets are available at www.nvent.com and from your nVent customer service representative. Improper installation, misuse, misapplication or other failure to completely follow nVent's instructions and warnings may cause product malfunction, property damage, serious bodily injury and death and/or void your warranty.



Our powerful portfolio of brands:

CADDY ERICO HOFFMAN ILSCO SCHROFF TRACHTE