



| □□□       | □□ | □□□□ | □□□□ | □□□□   | □□        | □□  |
|-----------|----|------|------|--|-----------|---|
| 21120-131 | □□ | 10   | M6   | RatiopacPRO,<br>RatiopacPRO<br>AIR,<br>CompacPRO,<br>PropacPRO,<br>Comptec,<br>Inpac,<br>MultipacPRO | □□□□ , □□ | □□□ ,<br>Eurorack,<br>Novastar,<br>Varistar,<br>Varistar CP |
| 21100-003 | □□ | 50   | M6   | RatiopacPRO,<br>RatiopacPRO<br>AIR,<br>CompacPRO,<br>PropacPRO,<br>Comptec,<br>Inpac,<br>MultipacPRO | □□□□      | □□□ ,<br>Eurorack,<br>Novastar,<br>Varistar,<br>Varistar CP |
| 21100-001 | □□ | 50   | M4   |  | □□□□      | □□□ ,<br>Eurorack,<br>Novastar,<br>Varistar,<br>Varistar CP |
| 21100-215 | □□ | 50   | M5   |  | □□□□      | □□□ ,<br>Eurorack,<br>Novastar,<br>Varistar,<br>Varistar CP |
| 21100-216 | □□ | 100  | M5   |  | □□□□      | □□□ ,<br>Eurorack,<br>Novastar,<br>Varistar,<br>Varistar CP |
| 21120-130 | □□ | 100  | M5   |  | □□□□ , □□ | □□□ ,<br>Eurorack,<br>Novastar,<br>Varistar,<br>Varistar CP |
| 21120-132 | □□ | 100  | M6   | RatiopacPRO,<br>RatiopacPRO<br>AIR,<br>CompacPRO,<br>PropacPRO,<br>Comptec,<br>Inpac,<br>MultipacPRO | □□□□ , □□ | □□□ ,<br>Eurorack,<br>Novastar,<br>Varistar,<br>Varistar CP |

